



1. Insert the dummy ball when the trailer is unhitched by lifting the handle upwards and coupling in the normal way.



2. With the handle fully down, place the cover over the hitch.



3. With the lock bolt in the unlocked position, insert it through both the holes of the cover. Fit the cup over the end of the lock bolt, then turn the key a quarter turn clockwise and remove.



4. To remove the hitch lock, insert the key, turn it a quarter turn anti clockwise and withdraw the lock from the cover. Remove the cover and dummy ball if fitted.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Bulldog Security Products Ltd

Units 1-4 Stretton Road, Much Wenlock, Shropshire TF13 6DH
Tel: 01952 728171 Fax: 01952 728117
Email: sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ballbearings with WD40 (or equivalent) minimum every four months.